

Seat Wall Kit SA-SW-3

Installation Instructions

Please Read This Entire Document and Familiarize Yourself with All Steps and Kit Parts Before Beginning Construction of the Concrete Pad or the Seat Wall Kit.

- **Materials required:** Landscape block adhesive or mortar.
- **Tools required:** Mallet or dead blow hammer, mason's or rock hammer, caulk gun, saw with masonry blade.
- **Finishing will require additional tools and materials based on the type of finish being applied.**

Notes: Panels may be trimmed with a masonry saw as needed for the application.

Pre-installation Preparation: Seat walls should be installed on a 4" steel-reinforced concrete pad or patio. Pier pad below frost line if required in your region. Construct the pad with an appropriate outside border, to serve as a support ledge for finish material, if required by the type of finish to be used.

Seat Wall kit is assembled by placing the panels as shown below, with brackets at top. Wall panels are 16" tall, Top panels are 12" wide. Brackets should be placed to span joints of multiple kits, to tie joints together. This may result in left over brackets, and does not indicate incorrect assembly.

Refer to Figure 1 for the number and layout of the panels, and Figure 2 for the types of brackets used in this kit. Unfinished Dimensions of the Seat Wall kit is 12" wide by 36" long by 18" tall.

Figure 1




Figure 2



Finishing Specifications

Model SA-SW-3: Side Area: 10 Square Feet, Corners: 6 Linear Feet